

CRIS



ANTI-SLIP CRYSTALLISER FOR TREATMENT OF MARBLE, MARBLE COMPOSITION AND TERRAZZO FLOORS

- Anti-slip effect tested by UL laboratories
- Eliminates porosity of calcareous floors
- Glossy effect



Crystalliser for calcareous floors. Eliminates micro-porosity by preventing dirt from penetrating. Excellent glossy effect. Registered with Underwriters Laboratories Inc. as anti-slip, high resistance product.

? HOW TO USE

After carefully removing wax using a wax stripper from the SUTTER PROFESSIONAL range, when the floor is completely dry, spray a small amount of the product (8-10 ml. per m2) directly onto the floor and use the single disc machine at a low speed (150/170 rpm minimum weight 45 kg) with steel wool pad (grade 00) until completely dry and polished (8-10 min per m2). Repeat if necessary. After treatment, damp mop with a disposal cloth.



SUTTER INDUSTRIES S.p.A Località Leigozze 1, 15060 Borghetto Borbera - Tel. +39 0143 631.1 www.sutterprofessional.com- info@sutterprofessional.com









CRIS

DILUTION

Ready to use.

FEATURES

Product yields (m²/lt):

Operation category	Conc.%	Product yield (m ² /lt)	Notes
MARBLE CRYSTALLIZING	RBLE CRYSTALLIZING 100%		Single disk machine equipped with extra weight and steel wool pad

Volume (It) of pure product diluted according to suggested dilutions.

R TECHNICAL DATA

ASPECT: Opaque liquid COLOR: Pink PERFUME: Floral COV: 5,10%

PH	Active substance [%]	Density (g/ml)	Pressure (bar)	Viscosity (cP)	Total dry residue [%]
1,5 ± 0,5	30 ± 2	1.14			

UWARNINGS

Harmful if swallowed. Causes severe skin burns and eye damage. Harmful to aquatic life with long lasting effects. Wear eye protection. IF SWALLOWED: rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/ shower. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician. Contents MAGNESIUMHEXAFLUOROSILICATE.



NOTES

Do not use CRIS at temperatures below 10° C. Keep away from freezing.

Before use, please always refer to the Technical Data Sheet and the Safety Data Sheet, with the exposure scenario, of the product. Use the PPE specified in the Safety Data Sheet.

Sutter Professional cannot be considered liable for any damage due to improper product use.

Only for professional use. Safety data sheet available on request.

SUTTER INDUSTRIES S.p.A

Località Leigozze 1, 15060 Borghetto Borbera - Tel. +39 0143 631.1 www.sutterprofessional.com- info@sutterprofessional.com







CRIS Code Size Quantity Pallet 5427 4 9x4=36 Kg 5

SUTTER INDUSTRIES S.p.A Località Leigozze 1, 15060 Borghetto Borbera - Tel. +39 0143 631.1 www.sutterprofessional.com- info@sutterprofessional.com Rev. 11/03/2024



