



TABS CHLORINE



DISINFECTING* EFFERVESCENT TABLETS CONTAINING DICHLOROISOCYANURATE

- EN Tests*: 1276, 1650, 13697, 14476, 16777
- High chlorine content
- Excellent solubility



Effervescent tablets with disinfectant* action based on dichloroisocyanurate for the disinfection of hard surfaces. The product can be used in food areas to clean and disinfect* surfaces, kitchen utensils and dishes. Rinse with plenty of drinking water after using.

COMPOSITION: 100g of product contain: Dichloroisocyanurate 80,77g. Co-formulants up to 100g.

In compliance with the following EN Tests standards*: 1276, 1650, 13697, 14476, 16777.

? HOW TO USE

- Disinfecting bactericidal and yesticidal action (hard surfaces): carefully clean the surface to treat, then dissolve 1 tablet in 5 litres of water, apply the solution directly on the surface, leave to act for 5 minutes for bactericidal action and 15 minutes for yeasticidal action.
- Disinfecting virucidal action (hard surfaces): carefully clean the surface to treat, then dissolve 1 tablet in 1 litres of water, apply the solution directly on the surface, leave to act for 60 minutes for virucidal action.
- To clean soaking dishes: dilute one tablet per washing cycle



DILUTION

Ready to use.









TABS CHLORINE

R TECHNICAL DATA



ASPECT: Pads COLOR: White PERFUME: Technical COV: 0,00%

PH	Active substance [%]	Density (g/ml)	Pressure (bar)	Viscosity (cP)	Total dry residue [%]
Sol. 1%: 6,5 ± 0,5	> 95	-			

Further Information: Each pack contains 150 tabs.

Each tab of 3,34g contains 2,70g of sodium dichloro isocyanurate dihydrate equal to 1,50g of active chlorine at origin.

WARNINGS

Harmful if swallowed. Causes serious eye irritation. May cause respiratory irritation. Very toxic to aquatic life with long lasting effects. Contact with acids liberates toxic gas. Warning! Do not use together with other products. May release dangerous gases (chlorine). Wear eye/face protection. IF SWALLOWED: Immediately call a POISON CENTER/doctor. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention. Store in a dry place. Store in a closed container. Store at temperatures not exceeding 40°C. Dispose of contents/container in accordance with applicable local regulations. Contains troclosene sodium, dihydrate.



NOTES

Store in an undamp and warm area. Before use, please perform a test on a small hidden portion of surface to make sure it is compatible and always refer to the Technical Data Sheet and the Safety Data Sheet, with the exposure scenario, of the product. Use the PPE specified in the Safety Data Sheet.

For further information about the EN Tests & Effectiveness Conditions, please check the "Test and Conditions" Annex.

Sutter Professional cannot be considered liable for any damage due to improper product use. Only for professional use. Safety data sheet available on request.

* Regulatory requirements surrounding the biocidal registration may vary according to each Country.

🗂 PAC	CKAGING			
	Code	Size	Quantity	Pallet
	567902	gr 500	12	12x6=72

SUTTER INDUSTRIES S.p.A

Località Leigozze 1, 15060 Borghetto Borbera - Tel. +39 0143 631.1 www.sutterprofessional.com- info@sutterprofessional.com

